

WISPEED

A black electric scooter with red accents is parked on a cobblestone street. The scooter has a black frame, a black deck, and black wheels. Red accents are visible on the frame and the wheels. The scooter is parked next to a brick wall. The background shows a long, multi-story brick building with many windows, stretching into the distance under a cloudy sky.

T850
Tutoriel : remplacer son
garde boue

PRÉAMBULE



Pour quel type de bricoleur ?

Occasionnel / Expérimenté / Professionnel



L'outillage nécessaire ?


- Clé allen de 2,5



Le temps estimé ?

Entre 5 et 10 minutes

LES OUTILS





Clé allen de 2,5

DÉMONTER ET REMONTER LE GARDE BOUE

Pour démonter et remonter le garde boue de votre trottinette, vous aurez besoin d'une **clé allen de 2,5**.

1

Retirer les 4 vis allen (taille 2,5) du garde boue situé à l'arrière du marche pied.



Replacer le nouveau garde boue et revisser les 4 vis allen (taille 2,5) sur le marche pied.